

T7EM

Klávesnice a čtečka  
karet.



## 2. Rychlé naprogramování

Vstup do programování	<div> <div>*</div> <div>Master code</div> <div>#</div> </div> <p>999999 defaultní master code z výroby</p>
Pro ukončení programování stiskněte	<div> <div>*</div> </div>
<b>Pamatujte, že pro provedení následujícího programování musí být Master uživatel přihlášen</b>	
Pro změnu Master Kódu	<div> <div>0</div> <div>Nový kód</div> <div>#</div> <div>Nový Kód</div> <div>#</div> </div> <p>Master kód může být 6 až 8 číslic dlouhý</p>
Vložení PINu uživatele.	<div> <div>1</div> <div>Číslo ID uživatele</div> <div>#</div> <div>PIN</div> <div>#</div> </div> <p>ID číslo uživatele je libovolné číslo mezi 1 a 2000. PIN jsou libovolné čtyři číslice mezi 0000 a 9999, s výjimkou 1234, která je zakázána. Uživatelé mohou být přidáváni nepřetržitě bez ukončení programovacího režimu</p>
Vložení karty uživatele	<div> <div>1</div> <div>Přiložte kartu</div> <div>#</div> </div> <p>Cards can be added continuously without exiting programming mode</p>
Vymazání PINu či karty uživatele.	<div> <div>2</div> <div>Číslo ID uživatele</div> <div>#</div> </div> <p>prouživatele PINu nebo</p> <div> <div>2</div> <div>Přiložte kartu</div> <div>#</div> </div> <p>pro uživatele karty</p> <p>Uživatelé mohou být průběžně mazáni, aniž by museli opustit programovací režim.</p>
Aktivovat zámek pomocí PINu	Zadejte <div>PIN</div> Stiskněte <div>#</div>
Aktivovat zámek pomocí karty	Přiložte kartu ke čtečce.

### 3. Description

The unit is single door multifunction standalone access controller **or** a Wiegand output keypad or card reader. It is suitable for mounting either indoor or outdoor in harsh environments. It is housed in a strong, sturdy and vandal proof Zinc Alloy electroplated case which is available in either a bright silver or matt silver finish. The electronics are fully potted so the unit is waterproof and conforms to IP68. This unit supports up to 2000 users in either a Card, 4 digit PIN, or a Card + PIN option. The inbuilt card reader supports 125KHZ EM cards, 13.56MHz Mifare cards. The unit has many extra features including lock output current short circuit protection, Wiegand output, and a backlit keypad. These features make the unit an ideal choice for door access not only for small shops and domestic households but also for commercial and industrial applications such as factories, warehouses, laboratories, banks and prisons.

### 4. Features

- Waterproof, conforms to IP68
- Strong Zinc Alloy Electroplated anti-vandal case
- Full programming from the keypad
- 2000 users, supports Card, PIN, Card + PIN
- Can be used as a stand alone keypad
- Backlight keys
- Wiegand 26 input for connection to external reader
- Wiegand 26 output for connection to a controller
- Adjustable Door Output time, Alarm time, Door Open time
- Very low power consumption (30mA)
- Fast operating speed, <20ms with 2000 users
- Lock output current short circuit protection
- Easy to install and program
- Built in light dependent resistor (LDR) for anti tamper
- Built in buzzer
- Red, Yellow and Green LEDS display the working status

### 5. Specifications

Operating Voltage	12V DC
User Capacity	2000
Card Reading Distance	3-6 cm
Active Current	<60mA
Idle Current	25±5 mA
Lock Output Load	Max 3A
Alarm Output Load	Max 20A
Operating Temperature	-45°C ~ 60°C
Operating Humidity	10%- 90% RH
Adjustable Door Relay time	0 -99 seconds
Adjustable Alarm Time	0- 3 minutes
Wiegand Interface	Wiegand 26 bit
Wiring Connections	Electric Lock, Exit Button, External Alarm

## 6. Installation

- Remove the back cover from the keypad using the supplied special screw driver
- Drill 2 holes on the wall for the Self tapping screws and 1 hole for the cable
- Put the supplied rubber bungs into the two holes
- Fix the back cover firmly on the wall with 2 Self tapping screws
- Thread the cable through the cable hole
- Attach the keypad to the back cover.


## 7. Wiring

Colour	Function	Description
Pink	BELL_A	Doorbell button one end
Pink	BELL_B	Doorbell button to the other end
Green	D0	WG output D0
White	D1	WG output D1
Grey	ALARM	Alarm negative(alarm positive connected 12 V+)
Yellow	OPEN	Exit button one end(the other end connected GND)
Brown	D_IN	Magnetic switch one end(the other end connected GND)
Red	12V+	12V + DC Regulated Power Input
Black	GND	12V - DC Regulated Power Input
Blue	NO	Relay normally-on end(Connect positive electric lock "-")
Purple	COM	Relay Public end, connect GND
Orange	NC	Relay Closed end(Connect negative electric lock "-")






common power supply diagram:



special power supply diagram:



## 8. To Reset to Factory Default

- Power on, press # and release it quickly when LED turns orange
- On hearing two "Di" sound, system is back to factory settings

**Please note only installer data is restored, user data will not be affected**

## 9. Anti Tamper Alarm

The unit uses a LDR (light dependent resistor) as an anti tamper alarm. If the keypad is removed from the cover then the tamper alarm will operate.

## 10. Sound and Light indication

Operation Status	Red Light	Green Light	Yellow Light	Buzzer
Power on	-	Bright	-	Di
Stand by	Bright	-	-	-
Press keypad	-	-	-	Di
Operation successful	-	Bright	-	Di
Operation failed	-	-	-	DiDiDi
Enter into programming mode	Bright	-	-	
In the programming mode	-	-	Bright	Di
Exit from the programming mode	Bright	-	-	Di
Open the door		Bright	-	Di
Alarm	Bright			Alarm

## 11. Detailed Programming Guide

### 11.1 User Settings

To enter the programming mode	* Master code # 999999 is the default factory master code
To exit from the programming mode	*
<b>Note that to undertake the following programming the master user must be logged in</b>	
To change the master code	0 New code # New code # The master code can be 6 to 8 digits long
<b>Setting the working mode:</b> Set valid card only users Set valid card <b>and</b> PIN users Set valid card <b>or</b> PIN users	3 0 # Entry is by card only 3 1 # Entry is by card <b>and</b> PIN together 3 2 # Entry is by either card <b>or</b> PIN (default)
<b>To add a user in either card or PIN mode, i.e. in the 3 2 # mode. (Default setting)</b>	

To add a <b>PIN</b> user	<p>1 [User ID number] [#] [PIN] [#]</p> <p>The ID number is any number between 1 &amp; 2000. The PIN is any four digits between 0000 &amp; 9999 with the exception of 1234 which is reserved. Users can be added continuously without exiting programming mode as follows:</p> <p>1 [User ID no 1] [#] [PIN] [#] [User ID no 2] [#] [PIN] [#]</p>
To delete a <b>PIN</b> user	<p>2 [User ID number] [#]</p> <p>Users can be deleted continuously without exiting programming mode</p>
To change the <b>PIN</b> of a PIN user (This step must be done out of programming mode)	<p>* [ID number] [#] [Old PIN] [#] [New PIN] [#] [New PIN] [#]</p>
To add a <b>card</b> user (Method 1) This is the fastest way to enter cards, user ID number auto generation.	<p>1 [Read card] [#]</p> <p>Cards can be added continuously without exiting programming mode</p>
To add a <b>card</b> user (Method 2) This is the alternative way to enter cards using User ID Allocation. In this method a User ID is allocated to a card. Only one user ID can be allocated to a single card.	<p>1 [ID number] [#] [Read card] [#]</p> <p>User can be added continuously without exiting programming mode</p>
To add a <b>card</b> user (Method 3) Card number is the last 8 digits printed on the back of the card, user ID number auto generation	<p>1 [Card number] [#]</p> <p>User can be added continuously without exiting programming mode</p>
To add a <b>card</b> user (Method 4) In this method a User ID is allocated to a card number. Only one user ID can be allocated to the card number	<p>1 [ID number. #] [Card number. #]</p> <p>User can be added continuously without exiting programming mode</p>
To delete a <b>card</b> user by card. Note users can be deleted continuously without exiting programming mode	<p>2 [Read Card] [#]</p>
To delete a <b>card</b> user by user ID. This option can be used when a user has lost their card	<p>2 [User ID] [#]</p>

To delete a <b>card</b> user by card number.  This option can be used when the user want to make the change but the card has lost	<b>2</b> <b>Card number</b> <b>#</b>  Note users can be deleted continuously without exiting programming mode
To add a <b>card and PIN</b> user in card and PIN mode ( <b>3</b> <b>1</b> <b>#</b> )	
To Add a <b>card</b> and <b>PIN</b> user  (The PIN is any four digits between 0000 & 9999 with the exception of 1234 which is reserved.)	Add the card as for a card user Press <b>1</b> to <b>exit from the programming mode</b> Then allocate the card a PIN as follows: <b>*</b> <b>Read card</b> <b>1234 #</b> <b>PIN #</b> <b>PIN #</b>
To change a <b>PIN</b> in card and PIN mode (Method 1) Note that this is done outside programming mode so the user can undertake this themselves	<b>*</b> <b>Read Card</b> <b>Old PIN #</b> <b>New PIN #</b> <b>New PIN #</b>
To change a <b>PIN</b> in card and PIN mode (Method 2) Note that this is done outside programming mode so the user can undertake this themselves	<b>*</b> <b>ID number #</b> <b>Old PIN #</b> <b>New PIN #</b> <b>New PIN #</b>
To delete a <b>Card and PIN</b> user just delete the card	<b>2</b> <b>User ID</b> <b>#</b>
To add a <b>card</b> user in card mode ( <b>3</b> <b>0</b> <b>#</b> )	
To Add and Delete a <b>card</b> user	The operating is the same as adding and deleting a card user in <b>3</b> <b>2</b> <b>#</b>
To delete <b>All users</b>	
To delete <b>ALL users</b> . Note that this is a <b>dangerous</b> option so use with care	<b>2</b> <b>0000</b> <b>#</b>
<b>To unlock the door</b>	
For a <b>PIN</b> user	Enter the <b>PIN</b> then press <b>#</b>
For a <b>card</b> User	<b>Read card</b>
For a <b>card and PIN</b> user	<b>Read card</b> then enter <b>PIN #</b>

## 11.2 Door Settings

<b>Relay Output Delay Time</b>	
To set door relay strike time	* [Master code] # [4] [0~99] # # 0-99 is to set the door relay time 0-99 seconds
<b>Door Open Detection</b> <i>Door Open Too Long (DOTL) warning.</i> When used with an optional magnetic contact or built-in magnetic contact of the lock, if the door is opened normally, but not closed after 1 minute, the inside buzzer will beep automatically to remind people to close the door and continue for 1 minute before switching off automatically. <i>Door Forced Open warning.</i> When used with an optional magnetic contact or built-in magnetic contact of the lock, if the door is forced open, or if the door is opened after 20 seconds, the inside buzzer and alarm output will both operate. The Alarm Output time is adjustable between 0-3 minutes with the default being 1 minute.	
To disable door open detection. (Factory default)	[6] [0] #
To enable door open detection	[6] [1] #
<b>Alarm output time</b>	
To set the alarm output time (0-3 minutes) Factory default is 1 minute	[5] [0~3] #
<b>Keypad Lockout &amp; Alarm Output options.</b> If there are 10 invalid cards or 10 incorrect PIN numbers in a 10 minute period either the keypad will lockout for 10 minutes or both the alarm and the inside buzzer will operate for 10 minutes, depending on the option selected below.	
Normal status: No keypad lockout or alarm (factory default)	[7] [0] # (Factory default setting)
Keypad Lockout	[7] [1] #
Alarm and inside buzzer operate	[7] [2] #
<b>To remove the alarm</b>	
To reset the Door Forced Open warning	[Read valid card] or [Master Code] #
To reset the Door Open Too Long warning	Close the door or [Read valid card] or [Master Code] #

## 12.The unit operating as a Wiegand Output Reader

In this mode the unit supports a Wiegand 26 bit output so the Wiegand data lines can be connected to any controller which supports a Wiegand 26 bit input.

